Step by step tutorial: of Meizu M2 note Boton Home

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com
Click on a tool for visit the website.

Head made of synthetic carbon steel with titanium handle

18,63 €

Professional Double Plastic Device Opening Tool

1,52 €

SIM card removal tool for all brands

1,61 €

Anti-static tweezer tips VETUS ESD-259A

5,69 €

Electrical dissipating clamps, in blister

3,97 €

Step 1 - Meizu m2 note

Specifications
Dimensions : 75.2 x 150.9 x 8.7 mm
Weight : 149 g
SoC : MediaTek MT6753
Processor : ARM Cortex-453, 1300 MHz, **Number of cores:** 8
Graphics processor : ARM Mali-T720 MP3, 450 MHz, **Number of cores:** 3 RAM: 2 GB, 800 MHz
Internal memory: 16 GB, 32 GB
Memory cards : microSD, microSDHC, microSDXC
Display: 5.5 in, IGZO, 1080 x 1920 pixels, 24 bit
Battery: 3100 mAh, Li-ion (lithium ion)
Operating system: FlyMe 4.5 (Android 5.0 Lollipop)
Camera: 4160 x 3120 pixels, 1920 x 1080 pixels, 30 fps
SIM card: Nano-SIM, Nano-SIM / microSD
Wi-Fi: a, b, g, n, n 5GHz, Dual band, Wi-Fi Hotspot, Wi-Fi Direct
USB: 2.0, Micro USB
Bluetooth : 4.0
Location / Navigation: GPS, A-GPS, GLONASS

Before starting, make sure that the mobile is turned off.

Step 2 - SIM and SD cards

Remove the tray with SIM and SD cards.



Step 3 - Screws

Remove the Pentalobe screws located on both sides of the charging connector.

Step 4 - Back case

Remove the back cover, using a plastic opening tool.

Step 5 - Speaker

Remove the 4 Phillips screws to remove the speaker module.

Step 6 - Bottom plate

Disconnect the interconnection flex and the lower end of the antenna coaxial cable.

Peel off the vibrator with a flat or curved tip tool.

Step 7

Remove the Phillips screw to remove the bottom plate.

Step 8 - Boton Home

Finally, we remove the Home button, carefully taking off the flex with the contacts.