



NadieMeLlamaGallina.com

Porque Yo Lo Reparo

Step by step tutorial: of Altice S70 Fingerprint reader

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com
Click on a tool for visit the website.



Head made of
synthetic carbon steel
with titanium handle

18,63 €



Set of 5 metal picks
for opening

3,09 €



Professional opening
plastic tool, iPlastix

7,56 €



tweezers ESD-11

2,51 €



Set of professional
tools for opening
smartphones and
tablets

18,97 €



6-in-1 screwdriver, K-
8107 with different
heads, in blister

7,52 €

Step 1 - We remove the back cover

We introduce with great care, a pick inside the back cover. If necessary, to facilitate this action, we can apply a little heat, so that the glue softens and it is easier to introduce the barb.





Step 2 - Remove intermediate housing

Unscrew the screws and with a slight lever remove the intermediate housing.





Step 3 - We release battery

We release the screws that cover the plate that protects the flex from the battery. If necessary, we can remove the fingerprint reader.





Step 4 - We remove the battery

We disconnect the flex that connects the battery to the board. And with great care, we will remove the battery, introducing a plastic tool for professional opening.





Step 5 - We remove fingerprint reader

We take off the fingerprint reader. And unscrew the screws that hold the flex protection plate.

We disconnect the flex and remove the fingerprint reader.



