

# Step by step tutorial: of Motorola Moto G9 Power Auxiliary board

For this tutorial you will need the following spared parts and tools that you cant get at our online store <u>Impextrom.com</u> Click on a tool for visit the website.



#### Step 1 - Tray

First of all we must extract the card tray, for this we will use an extraction tool.



## Step 2 - Back case



With the help of a plastic pick we will unhook all the edges of the housing, but before removing it we will have to be careful with the adhesive that is in the area of the rear cameras, and we must detach the fingerprint reader from the housing.



# Step 3 - Intermediate housing

We extract the nine Torx screws (T5) that hold the intermediate housing, and with the help of a flat-tipped tool we will remove it.







We disconnect the battery to work with greater safety.



### Step 5 - Speaker

We extract the eight Torx screws (T5) that hold the cover in which the speaker is located, and with the help of a flat tool we will unhook it.



We disconnect all the components that are connected to the auxiliary plate, remove the Torx screw (T5) that holds it, and with the help of a flat-tipped tool we will unhook the auxiliary plate that we are going to change.













