



NadieMeLlamaGallina.com

Porque Yo Lo Reparo

Step by step tutorial: of Primux Tech Ciclón 2 Quad core Volume keys

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com
Click on a tool for visit the website.



Opening Tool for
tablets, smartphones,
laptops and other
devices

4,34 €



Pinza antiestática
ESD redondeada

3,06 €

Step 1 - Primux Tech Ciclón 2 Quad core

Primux Tech Cyclone 2 Quad core characteristics

Processor

Processor RK3188 Quad-Core (Cortex A9 + Mali400)

Ram memory: 1 GB

Storage

Internal: 8 GB

External: MicroSD up to 32 GB

screen

Size: 10.1 "

Type: Capacitive Multi Touch

Resolution: 1280x800

Battery

Battery 3.7V Polymer Lithium

OS

Android OS version 4.2 JB

Camera

Front and Rear

Connectivity

Wi-Fi 802.11 b / g / n

3G with external USB see models

MicroSD slot

HDMI output

Put USB

Before starting, make sure the tablet is off.



Step 2 - Back cover

The back cover is easily removed. We recommend the special opening tool, since it allows you to disassemble the lid without damaging it or scratching it.



Step 3

Go around the entire contour with this tool that resembles a "pizza cutter" and separate the back cover.



Step 4 - Volume keys

Finally, remove the volume keys with tweezers.



