



NadieMeLlamaGallina.com

Porque Yo Lo Reparo

## Step by step tutorial: of Samsung Galaxy S6 Edge Power key

For this tutorial you will need the following spared parts and tools that you cant get at our online store [Impextrom.com](http://Impextrom.com)  
Click on a tool for visit the website.



Head made of synthetic carbon steel with titanium handle

18,63 €



Opening tool Smartphone, tablet

2,19 €



Manual hot air welder 8032

40,44 €



Special SAT 0.75mm high friction PVC pick

1,07 €



2.2" suction cup for disassembling smartphones

4,66 €



Electrical dissipating clamps, in blister

3,97 €



Smartphones and PC repair tool case

35,92 €

### Step 1 - Samsung Galaxy S6 Edge

#### Characteristics:

**Dimensions:** 142.1 x 70.1 x 7.0mm.

**Weight:** 132 grams.

**Display:** SuperAMOLED 5.1 inches, 1440 x 2560 pixels (577 dpi).

**Memory:** 32/64/128 GB (not expandable), RAM: 3GB.

**Processor:** Exynos 7420 (64 bits and 14 nm) 4x2.1GHz (A57) + 4x1.5GHz A53 // GPU Mali-T760.

**Front camera :** Secondary 5 MP (f1.9).

**Rear camera:** 16 MP (f1.9) with stabilization // UHD video.

**Operating system:** Android 5.0.2 with TouchWiz.



## Step 2 - Heat back cover

To begin with we will have to remove the back cover. This is very stuck so we will apply heat to soften the glue and with the help of a suction cup, we will pull this to facilitate the entrance of the plectrum.



## Step 3 - Take off back cover

Having entered the prong, we will carefully cover the contour to take off the lid.







## Step 4 - Screws and SIM card

To remove the center case, we will first remove the thirteen Phillips screws (PH # 00) and then the SIM card tray.





## Step 5 - Separate central housing

If we have already removed the screws and the tray, we can start to disengage the entire screen of the casing.





## Step 6 - Power key

Finally, we will disengage the pushbutton from the central housing and press the key from outside to remove it.





