



NadieMeLlamaGallina.com

Porque Yo Lo Reparo

Step by step tutorial: Control remoto Xiaomi Mi Drone Control dials of Xiaomi Mi Drone

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com
Click on a tool for visit the website.



Left dial (camera angle adjust) for remote control of Xiaomi Mi Drone

6,57 €



Professional Double Plastic Device Opening Tool

1,52 €



Pinza antiestática curva Baku ESD BK-15

3,50 €



Screwdriver with 8 heads Peng Fa 7339A

6,96 €



Opening tool Smartphone, tablet

2,19 €




Precision cutter with 1 cm handle

5,90 €

Step 1 - Remove screws

In order to remove the casing, first we will have to find and extract the screws. We will find two of them at the top, below the telephone stand. The other two are on the sides under the fastening rubbers. The screws are Phillips type (PH # 0).







Step 2 - Remove housing

Once the four screws have been removed, we can disengage the casing. Before removing it, we will disconnect the joystick from the motherboard.





Step 3 - Control dials

Remove the two Phillips screws (PH # 0) that hold the dial. Then we disengage it and disconnect it.
The steps to follow are the same for both dials.

