



NadieMeLlamaGallina.com

Porque Yo Lo Reparo

Step by step tutorial: of Wiko Lenny 3 Battery

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com
Click on a tool for visit the website.



Generic battery Wiko
Lenny 1 / Lenny 2 /
Lenny 3

4,97 €



Opening tool
Smartphone, tablet

2,19 €

Step 1 - Remove back casing

We start by removing the back cover, for this we introduce a flat tool between it and the frame. Sliding it around the contour, we will be able to disengage it.





Step 2 - Battery

To remove the battery we will lever in the lower hole. We can also do it directly with our hands.



