



NadieMeLlamaGallina.com

Porque Yo Lo Reparo

Step by step tutorial: of Samsung Galaxy XCover 4 Touch screen

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com
Click on a tool for visit the website.



Professional disassembly spatula for mobile phones and smartphones

2,71 €



Opening tool Smartphone, tablet

2,19 €



Pinza antiestática ESD redondeada

3,06 €



Flexible plastic card for easy opening

0,98 €



Special SAT 0.70mm PET pick, high friction and resistance

1,25 €

Step 1 - Remove back cover and battery

We start by removing the back cover with the help of an opening tool or directly with your hands. Then, in the same way, we remove the battery.





Step 2 - Take off touch screen

We will heat the screen to soften the adhesive and it will be easier to remove it.

Once hot, we introduce a spike between the screen and the frame to take it off.

We will be careful in the upper left because there is the flex of the digitizer.





Step 3 - Separate screen

With a card or a very flexible and fine tool, we will take off the display introducing this one below, very carefully so that it does not scratch.

Once the display is separated, we will disconnect it from the motherboard in order to remove the screen.





Step 4 - Touch screen

All you have to do is remove the front keys and disconnect the digitizer from the display in order to separate them.

