Step by step tutorial: of Primux Omega 6 4G Interconnection Flex

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com Click on a tool for visit the website.



Step 1 - characteristics

Screen: 5.5 inches

Resolution: 720x1280 HD

Battery: 2600 mAh / 3.7V Polymer Lithium

Processor: MTK6735M at 1Ghz 64Bit

RAM memory : 1Gb

Storage: 8Gb of internal storage, and external up to 32Gb.

Cameras: 13Mpx rear camera with auto focus, and 3Mpx front.

Operating System : Android OS version 5.1 Lollipop.





WWW.NADIEMELLAMAGALLINA.COM 1 of 13

First remove the battery cover, if necessary we will use a plastic opening tool, so as not to damage it.


















Step 3 - Battery

Remove the battery, if necessary use the opening tool from the previous step.







WWW.NADIEMELLAMAGALLINA.COM 3 of 13

We remove all the cards that are in the phone.














Remove the 11 Phillips screws that hold the intermediate housing.





Step 6 - Intermediate housing and side buttons

Using a plastic opening tool, we gradually remove the casing, and as we remove it, be careful with the side buttons because they can fall.









WWW.NADIEMELLAMAGALLINA.COM 5 of 13











WWW.NADIEMELLAMAGALLINA.COM 6 of 13

We disconnect all the flexes and remove all the components that are on the motherboard.













 $WWW. {\tt NADIEMELLAMAGALLINA.COM}$





Step 8









WWW.NADIEMELLAMAGALLINA.COM 8 of 13









Step 9

Remove the two Phillips screws that hold the motherboard.





WWW.NADIEMELLAMAGALLINA.COM 9 of 13

We turn the base bale and disconnect the interconnection flex.







Step 11 - Auxiliary plate

Disconnect the coaxial cable, take off the vibrator, carefully lift the auxiliary plate, and disconnect from the back the interconnection flex.

















WWW.NADIEMELLAMAGALLINA.COM 11 of 13

We remove the sticker, it is practically impossible to remove it without breaking, and finally, using a plastic opening tool, we are taking off the interconnection flex.













WWW.NADIEMELLAMAGALLINA.COM



WWW.NADIEMELLAMAGALLINA.COM 13 of 13