
## Step by step tutorial: of Apple iPhone 13 mini rear cameras

For this tutorial you will need the following spared parts and tools that you cant get at our online store <a href="Impextrom.com">Impextrom.com</a> Click on a tool for visit the website.



## Step 1 - Screws

To start we must remove the two Pentalobe screws (TS1) from the bottom of the phone.





WWW.NADIEMELLAMAGALLINA.COM 1 of 7





Step 2 - We apply heat

We apply heat to the screen to slightly soften the adhesive that holds it, and with the help of a suction cup and a fine tool we will unhook all the edges of the screen, bearing in mind that we will lift it to the left, as if from a book was about.









WWW.NADIEMELLAMAGALLINA.COM 2 of 7



Step 3 - We disconnect battery

We remove the Triwing screw (Y0.6) that holds the shield that covers the battery connector among others, and with the help of a flat-tipped tool we will disconnect it to work with greater security.









WWW.NADIEMELLAMAGALLINA.COM 3 of 7





Step 4 - Screen

We extract the two Triwing screws (Y0.6) and the Phillips screw (PH # 00) that hold the shield, and with the flat-tip tool we will disconnect the two connectors that join the screen to the motherboard.









WWW.NADIEMELLAMAGALLINA.COM 4 of 7







Step 5 - Armor

To remove the shield that covers the rear cameras, we must remove the three Phillips screws (PH # 00) that hold it.





WWW.NADIEMELLAMAGALLINA.COM 5 of 7






Step 6 - rear cameras

And to finish we will disconnect the connectors from the cameras and we will be able to remove them.









WWW.NADIEMELLAMAGALLINA.COM 6 of 7



